



SOMFY MOTOR USAGE CHART

This chart shows the recommended motor size for specific Larissa and Cantina awning sizes.

Width		Projection				
		5' 60"	6'10" 82"	8'6" 102"	10'2" 122"	11'6" 138"
Ft.	In.					
7	84	535A2				
8	96	535A2	535A2			
9	108	535A2	535A2	550R2		
10	120	535A2	535A2	550R2		
11	132	535A2	535A2	550R2	550R2	550R2
12	144	535A2	535A2	550R2	550R2	550R2
13	156	535A2	535A2	550R2	550R2	550R2
14	168	535A2	535A2	550R2	550R2	550R2
15	180	535A2	535A2	550R2	550R2	550R2
16	192	535A2	535A2	550R2	550R2	550R2
17	204	535A2	535A2	550R2	550R2	550R2
18	216	535A2	550R2	550R2	550R2	550R2
19	228	535A2	550R2	550R2	550R2	550R2
20	240	535A2	550R2	550R2	550R2	550R2
21	252	550R2	550R2	550R2	550R2	550R2
22	264	550R2	550R2	550R2	550R2	550R2
23	276	550R2	550R2	550R2	550R2	550R2
24	288	550R2	550R2	550R2	550R2	550R2
25	300	550R2	550R2	550R2	550R2	550R2
26	312	550R2	550R2	550R2	550R2	550R2
27	324	550R2	550R2	550R2	550R2	550R2
28	336	550R2	550R2	550R2	550R2	550R2
29	348	550R2	550R2	550R2	550R2	550R2
30	360	550R2	550R2	550R2	550R2	550R2



SOMFY MOTOR USAGE CHART

This chart shows the recommended motor size for specific Courtyard and Countess awning sizes.

Width		Projection				
		2'0"	2'8"	3'3"	3'11"	4'7"
Ft.	In.	24"	32"	39"	47"	55"
2	24	n/a	n/a	n/a	n/a	n/a
3	36	525A2	525A2	525A2	525A2	525A2
4	48	525A2	525A2	525A2	525A2	535A2
5	60	525A2	525A2	525A2	535A2	535A2
6	72	525A2	525A2	535A2	535A2	535A2
7	84	525A2	525A2	535A2	535A2	535A2
8	96	525A2	525A2	535A2	535A2	535A2
9	108	525A2	525A2	535A2	535A2	535A2
10	120	525A2	525A2	535A2	535A2	535A2
11	132	525A2	535A2	535A2	535A2	535A2
12	144	525A2	535A2	535A2	535A2	535A2
13	156	535A2	535A2	535A2	535A2	535A2

Minimum width to add a motor is 32".



SOMFY LT 50 RTS MANUAL OVERRIDE MOTORS

525A2 RTS CMO 535A2 RTS CMO 550R2 RTS CMO

12 ft cord 3 wire pigtail
S 1043020



12 ft cord 3 wire pigtail
S 1047010



6 ft cord 3 wire pigtail
S 1051012



Crown & Drive Set to fit 78 mm round groove tube S 9012239



Manual Override Kit includes mounting bracket S 9012348




OPTIONAL
motor cable, 3 wire pigtail
12 ft long S 9000979
18 ft long S 9001538
24 ft long S 9000980




OPTIONAL
motor cable with plug
12 ft long S 9012148
18 ft long S 9012150
24 ft long S 9012149




Eolis Wind Control Sensor S 9012499




Eolis 3D WireFree Wind/Motion Sensor S 9014400



Sunis WireFree RTS Sun Sensor S 9013075



Soliris Sun/Wind Control Sensor S 9012500



Telis 1 Transmitter S 1810632
or
Telis 1 Patio Waterproof Transmitter S 1810643



Telis 4 Transmitter S 1810633
or
Telis 4 Patio Waterproof Transmitter S 1810645



Telis Soliris Transmitter S 1810625

REQUIRED if using a Sunis Sun Sensor or a Soliris Sun/Wind Sensor, even if another transmitter and/or Decora switch is being used.



Decora RTS 1 Paddle Switch
Ivory S 1810598
White S 1810597



Paddle Switch Plate Cover
Ivory S 9011966
White S 9011967



Decora RTS 4 Paddle Switch
Ivory S 1810599
White S 1810595



SOMFY OREA RTS CASSETTE SYSTEM MOTORS

535A2 OREO RTS 550R2 OREO RTS

12 ft cord 3 wire pigtail
S 1037522



6 ft cord 3 wire pigtail
S 1037523



Crown & Drive Set to fit 78 mm round groove tube S 9012239



Mounting Bracket S 9910001




OPTIONAL
motor cable, 3 wire pigtail
12 ft long S 9203866
18 ft long S 9001537
24 ft long S 9001264




OPTIONAL
motor cable with plug
12 ft long S 9012145
18 ft long S 9012151
24 ft long S 9001264




Eolis Wind Control Sensor S 9012499




Eolis 3D WireFree Wind/Motion Sensor S 9014400




Sunis WireFree RTS Sun Sensor S 9013075




Soliris Sun/Wind Control Sensor S 9012500



Telis 1 Transmitter S 1810632
Telis 4 Transmitter S 1810633




Patio Waterproof Transmitter
Telis 1 S 1810643
Telis 4 S 1810645



Telis Soliris Transmitter S 1810635

REQUIRED if using a Sunis Sun Sensor or a Soliris Sun/Wind Sensor, even if another transmitter and/or Decora switch is being used.



Decora RTS 1 Paddle Switch
Ivory S 1810598
White S 1810597



Paddle Switch Plate Cover
Ivory S 9011966
White S 9011967



Decora RTS 4 Paddle Switch
Ivory S 1810599
White S 1810595

